

6 Series

Quick Reference Guide

v 1.0

PQR-6700-1.0-E

PROPRIETARY NOTICE

All pages of this document contain information proprietary to Advanced Mobile Payment Inc (AMP). This document shall not be duplicated, transmitted, used, or otherwise disclosed to anyone other than the organization or specific individuals to which this document is delivered, and then only for the purpose of evaluation of the AMP proposal. This restriction is applicable to all sheets of this document. AMP reserves the right to have the recipient return all copies of this document at any time.

© 2017 AMP Inc. All Rights Reserved

DOCUMENT PROPERTIES

Information

ID	PQR-6700-1.0-E
Title	Quick Reference Guide
Category	AMP POS 6 Series - 6700
Access Level	General

Version Control

Version	Date	Summary of Change	Updated by
1.0	Aug 2017	Initial version	R. Gibbs

Supported Hardware & Software

Version	Software Release	Supported Hardware Model
1.0+	1.0	AMP POS 6 Series - 6700

CONTENTS

1	Introduction	4
2	6 Series - 6700 Architecture	4
2.1	Front View	4
2.2	Back & Side View	5
2.3	Ports	5
3	General Precautions	6
4	Powering Device On/Off	6
5	Installing SIM/SAM Card	7
6	Troubleshooting Common Problems	8
7	Technical Specifications	9

The following items should be found inside the original packaging:


- 6 Series POS terminal
- AC power supply and plug
- Product Quick Reference Guide

1 Introduction

Engage customers in new ways with the AMP 6 Series' crystal clear 7" color touch display and video capabilities, all while accepting payment options that appeal to them with signature capture, chip and PIN, NFC/contactless, smartphone payments, electronic wallets and tap-and-go compatibility. The Android OS and ARM11 secure processor provide power and simple application development options to meet the most demanding needs of any multi-lane or self-checkout environment. Optimized for the next generation of value-added services, gift card issuing and support of loyalty schemes, the AMP 6 Series is the ultimate choice for a complete multimedia transaction solution.


2 6 Series - 6700 Architecture

2.1 Front View




1	Stylus pen
2	Touchscreen LCD display
3	LED indicators
4	NFC contactless reader
5	PIN privacy shield
6	EMV chip insert slot
7	Keypad
8	Magstripe reader

2.2 Back & Side View



1	Keyhole mounting slot
2	Kensington® security slot
3	Built-in speakers
4	Anti-slip rubber pads
5	SIM/SAM card compartment
6	Identification label
7	PIN privacy shield
8	Lanyard attachment point
9	Active stylus port
10	Reset button
11	Headphone input

2.3 Ports



1	Power
2	RS232
3	PUSB
4	USB - host
5	Optional configuration
6	LAN 1

3 General Precautions

Basic care and consideration should be used when handling, operating or installing the 6 Series terminal. This is a secure device, with both physical and logical tamper protection, and no attempt should be made by the user to open or service the device in any way other than approved troubleshooting methods. Keep these basic guidelines in mind to prolong the longevity and functionality of your product:

- Use only the dedicated power supply provided with the terminal to avoid damage to the device's electrical components
- Avoid spills or exposure to liquids, which could cause the terminal to short circuit
- Protect the terminal from impact, including: vibration, shaking, knocks, falling objects, being dropped, etc.
- Keep the terminal from environments that produce excessive dust, humidity, high or low temperatures or electromagnetic fields
- While charging, do not attach or remove any components to avoid damage to the internal circuitry
- There are no user-serviceable internal parts or mechanisms, do not try to open, modify or repair the device
- Be aware, this terminal contains a failsafe where all internal data will be erased immediately upon detection of tampering (such as opening the housing)
- If a fault occurs, immediately disconnect the power supply, discontinue use and contact your service provider to request repairs and diagnostics

4 Powering Device On/Off

Powering On the device

First ensure that the plug is inserted into a known working socket, then insert the DC jack into the power port on the 6 Series, the device will then power itself On.


Powering Off the device

Unplug the DC jack from the back of the terminal and it will power itself Off.

5 Installing SIM/SAM Card

Installation of a SIM/SAM card

- Open the rear cover to reveal the card slots
- With the exposed chip facing downward, and the angled corner oriented away from the slot, insert the card until it is seated right at the bottom of the slot
- Ensure that any installed cards are securely locked in place, and close the rear cover



Install the SIM/SAM card

6 Troubleshooting Common Problems

If problems occur with the terminal, try these simple troubleshooting methods to correct the fault, or contact a service representative to further diagnose the issue.

Problem	Troubleshooting
Nothing displayed on screen	Ensure the power is properly connected at the socket and DC jack
Unable to read card	Ensure that the slot is free of debris or foreign objects Swipe the card in both directions, and check if error has been corrected Check if the current card is operational, and test with a different card
Magnetic reader data read error	Swipe the card with constant speed, tight to the bottom edge of the slot Ensure the card strip is facing the screen and aligned properly with the slot Try swiping the card in the opposite direction
Chip card data read error	Ensure the chip portion is facing upwards, and is properly inserted into the slot Check the card for excessive scratches, dirt, or other damage
Contactless card data read error	Confirm that the card supports contactless communication Check whether the card is properly aligned above the contactless reader area
Communication error	Restart the terminal in order to re-establish communications Confirm that the SIM card is properly installed, and that its contacts are clean If using WiFi, check that the terminal's connection is enabled

If problems persist after completing these troubleshooting procedures, please contact your sales or service representative. **Do not** attempt to open the terminal or make further repairs.

7 Technical Specifications

The following are specifications detailing the overall capabilities of the AMP 6 Series, including optional or variable elements. To obtain the specifications for your individual terminals, refer to the original sales order or your sales representative for more information.

PROCESSOR	32-bit secure processor, Cortex A9, BCM58303, 1.25 GHz
MEMORY	8 GB flash, 1GB DDR3
DISPLAY	7 " 600x1024 IPS LCD capacitive touch screen, fully video capable, signature capture
CONNECTIVITY	WiFi, Bluetooth 4.0, RS232, USB host, USB OTG, LAN1, LAN2
CERTIFICATION	EMV 4.3 level I and II, PCI PTS 4.X, EMV contactless level I
CARD READERS	Bi-directional triple-track magstripe reader, landed smart card, NFC
OTHER	2 SAM slots, audio and video capability, SD card reader, POE, stylus, mic 8 line out
SECURITY	3DES Encryption, remote key injection, Master/Session and DUKPT Key Management
POWER	9.5V DC, 2.5A
PHYSICAL	(197x196x60mm) - (7.8x7.6x2.3") LxWxH
BUTTONS	10 alphanumeric keys, 3 function keys, 1 reset button, backlit
SYSTEM	Android OS 4.X
WEIGHT	770 g (1.7 lbs)
OPERATION	0°C ~ 50°C (32°F ~ 122°F), 10% -90% humidity (non-condensing)
STORAGE	-20°C ~ 60°C (-4°F ~ 140°F), 5% -95% humidity (non-condensing)